

Installation & Maintenance




HEPER USA LLC W227 N546 Westmound Drive Waukesha, 53186 Wisconsin, United States +1 312 910 9740 infoUS@hepergroup.com


TURA 4x16 LED (LL2036.758-US)





https://heperlighting.com/us/ll2036.758-us/





English (USA)

Safety



- The product must be installed in accordance with applicable NEC standards by a qualified electrician familiar with the installation of exterior lighting fixtures.

 $^{\rm -}$ The product must be operated under specified voltage at all times.

ig< - Do not install if parts are damaged.



- Power must be disconnected while installing or servicing to avoid electrical shock.

- Failing to comply with warnings and installation steps in this document might void warranty.

- Do not touch the light source.

- $\ensuremath{\overline{\mathsf{M}}}\xspace^{-1}$ as the temperature of the product is at a safe level before touching.

- Do not allow cables to touch sharp edges of metal parts or other sharp objects to avoid damage or abrasion.



- Check all of the cable connections including grounding before powering the product.

- Check the proper grounding of the metal housing before powering the product.

- Only use the product for its intended purposes.



- Do not use accessories not approved or recommended by HEPER.

 $_{\textcircled{R}}$ - Replace any broken/cracked protective surface with a new one



- Before disconnecting the cables connections, disconnect the luminaire from the electricity.

Installation

- Make sure that the wire connections are as shown on the 12th visual.

Replacement of the control gear

- Unlock the clip to reach the driver location.

- The electrical connection automatically will be blocked when the cap is opened. Make sure that the mechanism is locked which is on the side of the cap.


- To close the cap, push it to the back to unlock the mechanism and lock the clip as shown on the visual.

Cleaning - Maintenance

- The product was designed and manufactured to operate for a long

period of time. To ensure maximum lifespan of the product, regular (i.e. every six months) visual inspection and cleaning with a solvent-free cleaner using a soft cloth is recommended. - Do not clean or service while the product is power connected.

Disposal



- Electronic Equipment), luminaires must not be disposed of with
- other household waste. At the end of their life, luminaires must
- be taken to the appropriate local facility available for the disposal or recycling of electronic products.

Wiring Color Codes

- Ground GREEN
- Line BLACK
- Neutral WHITE
- Dim(+) RED/PURPLE
- Dim (-) GRAY/ORANGE

Disclaimer

- HEPER reserve the right to make technical and design changes.